




Quick Setup Guide

Grandstream GWN7062(E) Home Fibre Modem

Let's get your new Grandstream modem humming along for your home fibre. This is super straightforward, but just remember to hold off until we've sent you that email confirming your fibre connection is all good to go. Or, if you're keen to double-check, just give us a bell on **09 280 3672**.




STEP 1:

Get Connected To The Fibre Box

First things first, make sure your Fibre Box is switched on.

Grab that ethernet/data cable in the modem box, and plug one end into the '**NET1**' port on your Grandstream modem. The other end goes into the one of the '**GE**' or '**LAN**' ports on your Fibre box. You'll find the exact port number in that '**New Order**' email we sent, or just give us a shout if you need us to confirm it. Easy as that!



Quick Tip:


No Power Cable for the Fibre Box? No worries, **just ring us on 09 280 3672** and we'll sort out a fault request with the Fibre company for you.

STEP 2:

Power Up Your Modem

Now, plug your modem into the wall using the power cable. Give it about 15 minutes to do its thing. It's just setting itself up and might even restart a few times – totally normal.

You'll know it's ready when the light is **Solid Blue**. If the light isn't solid blue after **15 minutes**, it might mean there's a hiccup with your fibre connection. Give us a call on **09 280 3672** and we'll get a fault request lodged for you.



STEP 3:

What Do Those Lights Mean?

Just a handy guide to what the lights on your modem are telling you:

- **No light:** It's off, mate!
- **Solid Green:** It's just booting up or restarting.
- **Flashing Green:** It's getting a software update.
- **Solid Blue:** Hooray! Internet connected and ready to roll. Or your mesh network is all set up.
- **Flashing Blue:** It's applying some settings or restoring stuff.
- **Flashing Yellow:** No internet connection right now.
- **Flashing Red:** Doing a factory reset or it's locked.
- **Solid Red:** Software update failed, or mesh pairing didn't work.
- **Flashing Pink:** Looking for new mesh routers to join the party (flickers faster when adding them).
- **Solid Pink:** Mesh router pairing in progress.
- **Solid Yellow:** A mesh router has disconnected from the main one.

STEP 4:

Hook Up Your Devices Wirelessly (WiFi)

Time to get your devices online! Your laptop, phone, tablet – anything with WiFi can connect.

Flip your modem over, and you'll find your WiFi name (it says '**SSID**') and the password.

To connect:

1. Go to your device's WiFi settings.
2. Find your **WiFi name/SSID** in the list.
3. Select it and pop in the password. Done!




STEP 5:

Cable Up For A Steadier Connection (Optional)

For a really stable and often faster connection, you can plug in devices like your computer, laptop, or Smart TV directly with a cable.

Just grab an ethernet cable (we provide one, you can buy more from your local electronics shop) and plug it from the 'NET2' or 'NET3' port on your Grandstream modem to your device.



Need a Hand?

If anything's still got you scratching your head, no worries! Just flick us an email at:
support@wirelessnation.net

Or call our friendly Kiwi team on
09 280 3672
We're here to help!